

## MICRO BR® BR-80 System Update Version 1.06

### What you will need to update your BR-80

- BR-80
- SD Memory
  - \* The SD Memory needs to be formatted on a BR-80
- A computer with a USB connector (Windows, Mac)
- USB cable
- Exclusive AC Adaptor (PSA series sold separately) or brand-new alkaline batteries
  - \* You cannot use the USB bus power supply to update

### Cautions With The Update

- We recommend that you back your user data up to your computer before you perform the update. If a problem occurs and your user data is lost, you will be able to restore the data by reloading the data you saved. For details on the procedure, refer to the "Backing up to your computer" section of the Owner's Manual.
- Never apply this update data to any product other than the BR-80. This update data may destroy the data or system program of other products.
- Never power-off your BR-80 while the update is in progress. If a power failure or similar accident occurs during the update process, the BR-80 won't be able to start up in normal operating mode. This will require servicing, so you will need to contact Roland service center near you if this occurs.

### Version Check

Before you start, check the system program version of your BR-80.

1. Turn the BR-80's power off.
2. Turn the BR-80's power on. The version number will appear on the screen.
  - \* Do not perform the update if the product is already up-to-date.

### System Update Procedure

The complete update procedure includes two steps in the following order: loading the update files onto the BR-80's memory card and then updating the BR-80.

Instructions are as follows:

#### Loading Update Files

1. Open/extract the downloaded "br80\_sys\_v104.zip" file on your computer. Five files will appear in the window.
  - \* Do not change the names of any of the extracted files.
2. Turn on the power to the BR-80.

3. Set the USB mode to STORAGE before you connect the BR-80 to your computer:

- A. Press the MENU button.
- B. Cursor to "FUNCTION" and then press ENTER.
- C. Cursor to "USB" and then press ENTER.
- D. Turn the Dial to set USB MODE to "STORAGE".
- E. Press ENTER twice.
- F. Restart the BR-80. The unit's USB mode is now set to STORAGE.

4. Connect the BR-80 to your computer via a USB cable. A "BR-80 EBAND" icon will appear on your computer screen.

\* "Removable Disk (\*)" may appear instead of the "BR-80 EBAND" icon.

5. Copy (drag and drop) the following files included in the "br80\_sys\_v104" folder into the "BR-80 EBAND" icon.

\_BOOTPRG.ES\_  
\_BR80PRG.BR\_  
\_BR80SND.BR\_  
\_UPDINFO.BR\_

\* Do not place the update files into any folders.

\* Do not copy the "br80\_sys\_v106" folder. Copy only the four individual files listed above.

6. Disconnect the USB memory from your computer as follows.

Windows: Use the Safely Remove Hardware icon in the Windows task tray to unmount the BR-80 from your computer and then disconnect the USB cable.

Mac: Drag the Drive icon of the BR-80 into the trash in the dock and then remove the USB cable.

Update Procedure:

1. Power off the BR-80.
2. Hold down the [STOP] and [REC] buttons and then press the [POWER] button. When the "SYSTEM UPDATER" screen appears, release the [STOP] and [REC] buttons.
3. When the message "Update System ?" appears, press the [ENTER] button. The update process will begin. When the message "COMPLETE!!" appears, the update has finished.
4. Power off the BR-80. Your BR-80 has completed the update.
5. Verify that the BR-80 has been updated by powering on the BR-80. The version number will appear on the screen.
6. Delete the update files from the SD memory card by connecting to a computer before continuing using the BR-80.