

# Micro BR Preset Pattern List

Pattern Number (Intro)	Pattern Name (Abbreviation shown in display)	Initial Tempo	Time Signature	Pattern Length (in measures)					
				IN	V1	F1	V2	F2	E
PT:001	ROCK1	130	4/4	1	2	2	2	2	4
PT:007	ROCK2	130	4/4	2	2	2	2	2	4
PT:013	ROCK3	118	4/4	2	2	1	2	1	2
PT:019	ROCK4	118	4/4	4	2	1	2	1	4
PT:025	ROCK5	104	4/4	4	2	1	2	1	2
PT:031	ROCK6	86	4/4	1	4	1	4	1	2
PT:037	Hard Rock 1 (Hdrc1)	130	4/4	4	2	1	2	1	3
PT:043	Hard Rock 2 (Hdrc2)	98	4/4	2	4	1	4	1	2
PT:049	Hard Rock 3 (Hdrc3)	126	4/4	4	2	1	2	1	5
PT:055	Hard Rock 4 (Hdrc4)	120	4/4	3	2	1	2	1	3
PT:061	Hard Rock 5 (Hdrc5)	118	4/4	1	1	1	1	1	1
PT:067	HEAVY1 (HEVY1)	210	4/4	4	4	2	4	2	4
PT:073	HEAVY2 (HEVY2)	120	4/4	2	2	2	2	2	2
PT:079	HEAVY3 (HEVY3)	120	4/4	2	2	2	2	2	3
PT:085	HEAVY4 (HEVY4)	162	4/4	2	2	2	2	2	3
PT:091	HEAVY5 (HEVY5)	109	4/4	4	2	1	2	1	1
PT:097	POP1	118	4/4	2	2	1	2	1	4
PT:103	POP2	118	4/4	2	2	1	2	1	2
PT:109	POP3	118	4/4	2	2	1	2	1	2
PT:115	POP4	118	4/4	2	1	1	1	1	4
PT:121	POP5	140	4/4	2	1	1	1	1	2
PT:127	POP6	96	4/4	2	2	1	2	1	2
PT:133	POP7	66	4/4	3	2	1	2	1	2
PT:139	POP8	151	4/4	4	2	1	4	1	3
PT:145	BALLAD1 (BALD1)	70	4/4	4	2	1	2	1	3
PT:151	BALLAD2 (BALD2)	89	4/4	1	2	1	2	1	2
PT:157	BLUES1 (BLUS1)	124	4/4	1	4	1	4	1	3
PT:163	BLUES2 (BLUS2)	192	4/4	4	4	1	4	1	4
PT:169	BLUES3 (BLUS3)	124	4/4	2	2	1	2	1	3
PT:175	BLUES4 (BLUS4)	148	4/4	4	2	1	2	1	2
PT:181	R&B1	110	4/4	4	2	1	2	1	3
PT:187	R&B2	154	4/4	2	2	1	2	1	5
PT:193	R&B3	108	4/4	4	2	1	2	1	3
PT:199	R&B4	96	4/4	4	4	1	4	1	1
PT:205	R&B5	94	4/4	4	2	1	2	1	4
PT:211	JAZZ1	140	4/4	2	2	2	2	2	2
PT:217	JAZZ2	140	4/4	4	2	2	2	2	2
PT:223	JAZZ3	140	4/4	4	4	1	4	1	5
PT:229	FUSION1 (FUSN1)	120	4/4	4	4	1	4	1	4
PT:235	FUSION2 (FUSN2)	118	4/4	1	2	1	2	1	3
PT:241	HipHop1 (H.Hp1)	93	4/4	1	4	1	4	1	1
PT:247	HipHop2 (H.Hp2)	102	4/4	2	4	1	4	1	2
PT:253	FUNK	110	4/4	1	2	2	2	2	1
PT:259	HOUSE	114	4/4	2	2	1	2	1	2
PT:265	Country1 (Cnty1)	118	4/4	2	1	1	1	1	1
PT:271	Country2 (Cnty2)	118	4/4	1	2	1	2	1	2
PT:277	OTHER1 (Othr1)	96	4/4	1	4	1	2	1	2
PT:283	OTHER2 (Othr2)	118	4/4	4	2	2	2	2	4
PT:289	OTHER3 (Othr3)	125	4/4	1	2	1	2	1	2
Metronome Time Signature									
PT:295	Metronome (Metro)	1/1	2/1	3/1	4/1	5/1	6/1	7/1	8/1
PT:303	Metronome (Metro)	1/2	2/2	3/2	4/2	5/2	6/2	7/2	8/2
PT:311	Metronome (Metro)	1/4	2/4	3/4	4/4	5/4	6/4	7/4	8/4
PT:319	Metronome (Metro)	1/8	2/8	3/8	4/8	5/8	6/8	7/8	8/8
PT:327	BREAK								